


## APT407 - Screwdriver



Ref. #	PCL Part No	Description
1	NOT AVAILABLE	Housing
2	NOT AVAILABLE	Pin
3	NOT AVAILABLE	Air Inlet
4	NOT AVAILABLE	Trigger
5	NOT AVAILABLE	Valve Stem
6	NOT AVAILABLE	Reverse Bushing
7	SEE SERVICE KIT	O-ring
7A	SEE SERVICE KIT	O-ring
8	SEE SERVICE KIT	Valve Spring
9	SEE SERVICE KIT	O-ring
10	NOT AVAILABLE	Reverse Lever
13	SEE REPAIR KIT	Ball Bearing
14	NOT AVAILABLE	End Plate
15	NOT AVAILABLE	Rotor
16	SEE REPAIR KIT	Rotor Blades
17	NOT AVAILABLE	Pin
18	NOT AVAILABLE	Cylinder
19	SEE REPAIR KIT	Spacer
20	SEE SERVICE KIT	Spring
21	NOT AVAILABLE	Spring Guide
22	NOT AVAILABLE	Internal Gear
23	NOT AVAILABLE	Planet Gear
24	NOT AVAILABLE	Pin
26	NOT AVAILABLE	Work Spindle
27	NOT AVAILABLE	Ball Bearing
28	NOT AVAILABLE	Clamp Nut
29	NOT AVAILABLE	Drive Dog
30	NOT AVAILABLE	Retaining Ring
31	NOT AVAILABLE	Retaining Ring
32	NOT AVAILABLE	Cam Spindle
33	NOT AVAILABLE	Steel Ball
34	NOT AVAILABLE	Clutch Carrier
35	NOT AVAILABLE	Steel Ball
36	SEE REPAIR KIT	Washer
37	SEE SERVICE KIT	Spring
38	SEE REPAIR KIT	Washer
39	NOT AVAILABLE	Adjust Nut
40	SEE REPAIR KIT	Spacer
41	NOT AVAILABLE	Clutch Housing
42	NOT AVAILABLE	Ball Retainer
43	SEE SERVICE KIT	Spring
44	NOT AVAILABLE	Washer
46	SEE SERVICE KIT	Set Screw
47	SEE SERVICE KIT	O-ring
48	NOT AVAILABLE	Exhaust Diffuser
49	NOT AVAILABLE	Screw
N/A	APTR407	APT407 Repair Kit (items: 13,16,19,36,38,40,44)
N/A	APTS407	APT407 Service Kit (items: 7,7A,8,9,20,37,43,46,47)